

Tarkett Home Luxury Floors Care & Maintenance



NUGEN™ | PIN OAK | DRIFT

Protect the investment you made by following these basic steps immediately after installing your Tarkett Home Luxury Flooring:

- When moving heavy furniture or appliances, do not slide directly over your floor. Place plywood or hardboard panels on floor when moving furniture or appliances.
- Do not wash floor for 48 hours after installation.
- Maintain post installation temperature between 55°F and 100°F. Maintain relative humidity between 40% and 70%.

Basic Floor Protection

- Moving furniture and appliances may cause scratches or indentations in your new floor. Make sure furniture and appliances are equipped with proper, non-staining rests, glides or casters.
- High heeled shoes can cause permanent damage to many types of flooring, including tile and plank.
- Repeated exposure to direct sunlight may cause fading or discoloration. Close drapes or blinds to block direct sunlight.
- The use of non-staining, latex-backed mats at entryways is helpful in removing grit that may abrade or scratch your floor. Caution: Discoloration can occur from rubber backings and dyes used in floor mats and rugs. Floor paints and driveway sealers can also permanently discolor your floor.
- Home appliances such as refrigerators and heating system air ducts emit a direct flow of heat that, if not controlled, can exceed 120°F. This condition may cause discoloration over time. Forced air heating system dampers should be adjusted to control outlet temperature to a maximum 100°F. Cigarettes, matches and other hot objects dropped on the floor can also cause permanent damage.

Routine Maintenance

Tarkett Home Luxury Flooring is easy to clean and maintain. For day-to-day maintenance, the following are some simple steps that will help keep your new floor looking great:

- Sweep or vacuum* regularly to remove dirt and grit that may abrade or scratch your new floor.
- Wipe up spills promptly and thoroughly with a damp cloth or mop.
- After a period of time, it may be necessary to wash the floor with **Tarkett Home Multi-Surface Flooring Cleaner** or equal neutral floor cleaner. Follow the detailed instructions in the CPP.
- Do not use dishwashing detergent. Any detergent film left on the floor can hold tracked-in dirt and leave the surface with a dull, cloudy appearance.

* Do not use beater bars on any vacuums to avoid damage



Tarkett North America

www.TarkettHome.com



Connect with us @TarkettHome



Scan this code to visit www.TarkettHome.com

Tarkett
Home